

LM3481-FlybackEVM

User's Guide



Literature Number: SNVU528
May 2016

1	Introduction.....	3
2	Specification Summary.....	4
3	Setup.....	4
	3.1 Input and Output Connector Descriptions.....	4
	3.2 Test Points	4
	3.3 Test Bench Setup	5
4	Performance.....	5
	4.1 Efficiency	6
	4.2 Load Transient	6
	4.3 Output Voltage Ripple	7
	4.4 Voltage Overshoot on SW Pin.....	9
5	Complete Schematic	11
6	Bill of Materials	12
7	PCB Layout	14

LM3481-FlybackEVM User's Guide

1 Introduction

The LM3481-Flyback Evaluation Module helps designers evaluate the operation and performance of the LM3481 boost controller in an isolated flyback design with a wide input voltage. The design accepts an input voltage range of 5 V to 32 V and provides an isolated output of 12 V_{out} capable of supplying 2 A of current to the load. The switching frequency is externally set at a nominal 130 kHz.




Figure 1. LM3481-Flyback Evaluation Board – Top View

The LM3481 device is a versatile low-side N-FET high-performance controller for switching regulators. The device is designed for use in Boost, SEPIC, and Flyback converters and topologies requiring a low-side FET as the primary switch. The switching frequency of the LM3481 device can be adjusted to any value between 100 kHz and 1 MHz by using a single external resistor or by synchronizing it to an external clock. Current mode control provides superior bandwidth and transient response in addition to cycle-by-cycle current limiting. Current limit can be programmed with a single external resistor. The LM3481 data sheet ([SNVS346](#)) gives a complete description of the part, operation, and application information.

2 Specification Summary

A summary of the LM3481-FlybackEVM specifications is provided in [Table 1](#). The ambient temperature is 25°C for all measurements, unless otherwise noted.

Table 1. LM3481-FlybackEVM Specification Summary

Specification ⁽¹⁾	Test Conditions	MIN	TYP	MAX	UNIT
V _{IN} voltage range		5	12	32	V
Output voltage			12		V
Line regulations	I _{OUT} = 2 A, V _{IN} = 5 V to 32 V		±0.1%		
Operating frequency			130		kHz
Maximum output current		2			A
Efficiency	V _{IN} = 24 V, I _{OUT} = 2 A		88%		

⁽¹⁾ Specifications are at T_A = 25°C

3 Setup

This section describes how to connect, set up, and use the LM3481-Flyback Evaluation Board input and output connectors.

3.1 Input and Output Connector Descriptions

[Table 2](#) describes input and output connectors on the LM3481-FlybackEVM.

Table 2. Input and Output Connectors

Ref	Name	Description
J1	VIN	Positive input power terminal for the EVM.
J2	GND	Return input power terminal for the EVM.
J3	VOUT	Positive output power terminal for the EVM.
J4	ISO GND	Isolated ground or return terminal for the output.
Vin	Vin	Input voltage sense terminal.
TP_GND	TP_GND	Input ground sense terminal.
Vout	Vout	Output voltage sense terminal.
ISOGND	ISOGND	Isolated output ground sense terminal.

3.2 Test Points

[Table 3](#) describes the test points on the LM3481-FlybackEVM.

Table 3. Test Points

Ref	Name	Description
SW	SW	Primary switch node test point.
ISEN	ISEN	Primary side current sense test point.
D_SW	D_SW	Secondary switch node test point.
Loop_1 Loop_2	Loop_1 Loop_2	Loop response measurement test points.

3.3 Test Bench Setup




Figure 2. Test Bench Setup

Figure 2 shows a typical test bench setup for the LM3481-FlybackEVM. The power supply and the load should be capable of handling the input and output voltage and current rating of the board. Follow these steps to properly set up the LM3481-FlybackEVM.

1. Connect the power and ground connectors VIN (J1) and GND (J2) to the power supply.
2. Connect an ammeter in series with the input if needed.
3. Connect a voltmeter across the input terminals (Vin, TP_GND).
4. Connect a resistive load or an electronic load across terminals VOUT (J3) and ISO GND (J4).
5. An ammeter can be inserted in series with the load to observe the load current.
6. Connect a voltmeter across the output sense terminals (Vout, ISO GND) to observe the output voltage.
7. With the load initially set to no load, set the power supply between 5 V and 32 V and turn on the power supply. Check for 12 V at the output.
8. Once the output is at the expected target (12 V), increase the load gradually within the operating range (0–2 A).

4 Performance

Figure 3 shows how to place the scope probe for measuring the input or output capacitor.




Figure 3. Proper Scope Probe Placements for Measuring Input or Output Capacitor

4.1 Efficiency

Figure 4 shows the efficiency for the LM3481-Flyback Evaluation Module.




Figure 4. Efficiency vs Output Load

4.2 Load Transient

Figure 5 shows the LM3481-FlybackEVM response to load transients. The current step is from 50% to 100% of maximum rated load at $V_{IN} = 12$ V. The current step slew rate is $70 \text{ mA}/\mu\text{s}$. Total peak-to-peak voltage variations is as shown, including ripple and noise on the output. Figure 6 shows the LM3481-FlybackEVM loop-response characteristics. Gain and phase plots are shown for V_{IN} voltage of 12 V with load current of 2 A. The loop-response measurement is taken by replacing R8 with a $49.9\text{-}\Omega$ resistor. The signal is then injected across R8 with test points Loop_1 and Loop_2.




Figure 5. Load Transient Response at 12 VIN




Figure 6. Loop Response at 12 VIN

Figure 7 shows the LM3481-FlybackEVM response to load transients at 20 VIN. Figure 8 shows the LM3481-FlybackEVM loop-response characteristics. Gain and phase plots are shown for VIN voltage of 20 V with load current of 2 A.




Figure 7. Load Transient Response at 20 VIN




Figure 8. Loop Response at 20 VIN

4.3 Output Voltage Ripple

Figure 9 shows the output voltage ripple and rectifier diode switching waveform (anode to ISO GND) for the LM3481-FlybackEVM. The output current is the rated full load of 2 A and VIN = 5.5 V. The ripple voltage is measured directly across C10.





Figure 9. Maximum Load Output Voltage Ripple at VIN = 5.5 V


Figure 10 shows the output voltage ripple and rectifier diode switching waveform (anode to ISO GND) for the LM3481-FlybackEVM at 12 VIN and 2 A of output Load.



Time base: 5 μs/div

Figure 10. Maximum Load Output Voltage Ripple at VIN = 12 V


Figure 11 shows the output voltage ripple and rectifier diode switching waveform (anode to ISO GND) for the LM3481-FlybackEVM at 28 VIN and 2 A of output Load.



Time base: 5 μs/div

Figure 11. Maximum Load Output Voltage Ripple at VIN = 28 V

Figure 12 shows the output voltage ripple and switching waveform for the LM3481-FlybackEVM while operating in discontinuous conduction mode (DCM). The input voltage is 28 V and the output is loaded with 0.75 A of Load.




Time base: 5 μ s/div

Figure 12. DCM Output Voltage Ripple


4.4 Voltage Overshoot on SW Pin

Figure 13 and Figure 14 show the voltage overshoot on the primary SW pin with 200 MHz bandwidth. This is measured with 12 V input voltage and 2 A output current.



Time base: 5 μ s/div


Figure 13. Primary Switch Node at 12 VIN



Time base: 500 ns/div


Figure 14. Primary Switch Node Overshoot- Zoomed in at 12 VIN

Figure 15 and Figure 16 show the voltage overshoot on the primary SW pin with 200 MHz bandwidth. This is measured with 12 V input voltage and 2 A output current.



Time base: 10 μs/div

Figure 15. Primary Switch Node at 28 VIN



Time base: 1 μs/div

Figure 16. Primary Switch Node Overshoot Zoomed in at 28 VIN

5 Complete Schematic

Figure 17 shows the schematic of the LM3481-Flyback evaluation board.




Figure 17. LM3481-FlybackEVM Schematic

6 Bill of Materials

Table 4. Bill of Materials

Item	Designator	Description	Manufacturer	Part Number	Qty
1	!PCB1	Printed Circuit Board	Any	SV601295	1
2	C1, C2	CAP, CERM, 2200 pF, 2000 V, $\pm 10\%$, X7R, 1812	TDK	C4532X7R3D222K130KA	2
3	C3	CAP, AL, 330 μ F, 35 V, $\pm 20\%$, 0.06 Ω , SMD	Panasonic	EEE-FP1V331AP	1
4	C4	CAP, CERM, 10 μ F, 50 V, $\pm 20\%$, X7R, 1210	TDK	C3225X7R1H106M250AC	1
5	C5	CAP, CERM, 3.3 μ F, 50 V, $\pm 10\%$, X7R, 1210	MuRata	GRM32DR71H335KA88L	1
6	C6	CAP, CERM, 0.22 μ F, 100 V, $\pm 10\%$, X7R, 0805	Samsung Electro-Mechanics	CL21B224KCF5NWE	1
7	C7, C8, C9, C10	CAP, CERM, 22 μ F, 25 V, $\pm 20\%$, X5R, 1210	AVX	12103D226MAT2A	4
8	C11	CAP, CERM, 330 pF, 100 V, $\pm 10\%$, X7R, 0603	AVX	06031C331KAT2A	1
9	C12	CAP, CERM, 2200 pF, 50 V, $\pm 10\%$, X7R, 0603	Kemet	C0603C222K5RACTU	1
10	C15, C19	CAP, CERM, 1 μ F, 25 V, $\pm 10\%$, X7R, 0603	Kemet	C0603C105K3RACTU	2
11	C16	CAP, CERM, 0.22 μ F, 50 V, $\pm 10\%$, X7R, 0805	TDK	C2012X7R1H224K125AA	1
12	C17	CAP, CERM, 1 μ F, 50 V, $\pm 10\%$, X7R, 0805	TDK	C2012X7R1H105K125AB	1
13	C20, C21	CAP, Aluminum Polymer, 270 μ F, 25 V, $\pm 20\%$, 0.027 Ω , D10xL12.7 mm SMD	Nichicon	PCV1E271MCL1GS	2
14	C22	CAP, CERM, 0.1 μ F, 50 V, $\pm 10\%$, X7R, 0603	TDK	C1608X7R1H104K080AA	1
15	D1	Diode, Schottky, 100 V, 10 A, TO-277A	Vishay-Semiconductor	V10P10-M3/86A	1
16	D2	Diode, Schottky, 100 V, 1 A, PowerDI123	Diodes Inc.	DFLS1100-7	1
17	D4, D5	Diode, Switching, 75 V, 0.15 A, SOT-323	Diodes Inc.	BAS16W-7-F	2
18	D_SW, ISEN, ISOGND, Loop_1, Loop_2, SW, TP_GND, Vin, Vout	Test Point, Miniature, SMT	Keystone	5015	9
19	H1, H2, H3, H4	Machine Screw, Round, #4-40 $\times$ 1/4, Nylon, Philips panhead	B&F Fastener Supply	NY PMS 440 0025 PH	4
20	H5, H6, H7, H8	Standoff, Hex, 0.5"L #4-40 Nylon	Keystone	1902C	4
21	J1, J2, J3, J4	Standard Banana Jack, Uninsulated, 5.5 mm	Keystone	575-4	4
22	LBL1	Thermal Transfer Printable Labels, 1.250" W $\times$ 0.250" H - 10,000 per roll	Brady	THT-13-457-10	1
23	Q1	MOSFET, N-CH, 80 V, 100 A, DNK0008A	Texas Instruments	CSD19502Q5B	1
24	R1	RES, 10.0, 1%, 0.1 W, 0603	Vishay-Dale	CRCW060310R0FKEA	1
25	R2	RES, 60.4 k, 1%, 0.1 W, 0603	Vishay-Dale	CRCW060360K4FKEA	1
26	R3	RES, 49.9, 1%, 0.25 W, 1206	Yageo America	RC1206FR-0749R9L	1
27	R4	RES, 4.7 Ω , 5%, 0.1W, 0603	Vishay-Dale	CRCW06034R70JNEA	1
28	R5	RES, 25.5 k, 0.1%, 0.1 W, AEC-Q200 Grade 0, 0603	Panasonic	ERA-3AEB2552V	1
29	R6	RES, 100, 1%, 0.1 W, 0603	Vishay-Dale	CRCW0603100R0FKEA	1
30	R8	RES, 0, 5%, 0.1 W, 0603	Vishay-Dale	CRCW06030000Z0EA	1
31	R9	RES, 0.006, 1%, 1 W, 2010	Rohm	PMR50HZPFU6L00	1
32	R10	RES, 4.70 k, 1%, 0.1 W, 0603	Yageo America	RC0603FR-074K7L	1
33	R11	RES, 10.0 k Ω , 1%, 0.1W, 0603	Vishay-Dale	CRCW060310K0FKEA	1

Table 4. Bill of Materials (continued)

Item	Designator	Description	Manufacturer	Part Number	Qty
34	R12, R17	RES, 374, 1%, 0.1 W, 0603	Vishay-Dale	CRCW0603374RFKEA	2
35	R13	RES, 162 k, 1%, 0.1 W, 0603	Vishay-Dale	CRCW0603162KFKEA	1
36	R14	RES, 3.00 k, 1%, 0.1 W, 0603	Yageo America	RC0603FR-073KL	1
37	R16	RES, 3.83 k, 0.1%, 0.1 W, 0603	Susumu Co Ltd	RG1608P-3831-B-T5	1
38	R18	RES, 1.00 k, 0.1%, 0.1 W, 0603	Susumu Co Ltd	RG1608P-102-B-T5	1
39	R19, R20	RES, 1.0 k, 5%, 0.75 W, 2010	Vishay-Dale	CRCW20101K00JNEF	2
40	T1	Transformer, 12 uH, SMT	Würth Elektronik	750316152	1
41	U1	High Efficiency Low-Side N-Channel Controller for Switching Regulators, 10-pin MSOP, Pb-Free	Texas Instruments	LM3481MM/NOPB	1
42	U2	Optocoupler, 5 kV, 50-600% CTR, TH-4	Lite-On	LTV-817S	1
43	U3	Adjustable Precision Shunt Regulator, 34 ppm / °C, 100 mA, –40 to 85 °C, 3-pin SOT-23 (DBZ), Green (RoHS and no Sb/Br)	Texas Instruments	TL431AIDBZR	1
44	FID1, FID2, FID3	Fiducial mark. There is nothing to buy or mount.	N/A	N/A	0

7 PCB Layout

Figure 18 through Figure 21 shows the board layout for the LM3481-FLYback EVM.




Figure 18. Top Layer




Figure 19. Mid Layer 1




Figure 20. Mid Layer 2




Figure 21. Bottom Layer

STANDARD TERMS AND CONDITIONS FOR EVALUATION MODULES

1. *Delivery:* TI delivers TI evaluation boards, kits, or modules, including any accompanying demonstration software, components, or documentation (collectively, an "EVM" or "EVMs") to the User ("User") in accordance with the terms and conditions set forth herein. Acceptance of the EVM is expressly subject to the following terms and conditions.

- 1.1 EVMs are intended solely for product or software developers for use in a research and development setting to facilitate feasibility evaluation, experimentation, or scientific analysis of TI semiconductors products. EVMs have no direct function and are not finished products. EVMs shall not be directly or indirectly assembled as a part or subassembly in any finished product. For clarification, any software or software tools provided with the EVM ("Software") shall not be subject to the terms and conditions set forth herein but rather shall be subject to the applicable terms and conditions that accompany such Software
- 1.2 EVMs are not intended for consumer or household use. EVMs may not be sold, sublicensed, leased, rented, loaned, assigned, or otherwise distributed for commercial purposes by Users, in whole or in part, or used in any finished product or production system.

- 2 *Limited Warranty and Related Remedies/Disclaimers:*

- 2.1 These terms and conditions do not apply to Software. The warranty, if any, for Software is covered in the applicable Software License Agreement.
- 2.2 TI warrants that the TI EVM will conform to TI's published specifications for ninety (90) days after the date TI delivers such EVM to User. Notwithstanding the foregoing, TI shall not be liable for any defects that are caused by neglect, misuse or mistreatment by an entity other than TI, including improper installation or testing, or for any EVMs that have been altered or modified in any way by an entity other than TI. Moreover, TI shall not be liable for any defects that result from User's design, specifications or instructions for such EVMs. Testing and other quality control techniques are used to the extent TI deems necessary or as mandated by government requirements. TI does not test all parameters of each EVM.
- 2.3 If any EVM fails to conform to the warranty set forth above, TI's sole liability shall be at its option to repair or replace such EVM, or credit User's account for such EVM. TI's liability under this warranty shall be limited to EVMs that are returned during the warranty period to the address designated by TI and that are determined by TI not to conform to such warranty. If TI elects to repair or replace such EVM, TI shall have a reasonable time to repair such EVM or provide replacements. Repaired EVMs shall be warranted for the remainder of the original warranty period. Replaced EVMs shall be warranted for a new full ninety (90) day warranty period.

- 3 *Regulatory Notices:*

- 3.1 *United States*

3.1.1 *Notice applicable to EVMs not FCC-Approved:*

This kit is designed to allow product developers to evaluate electronic components, circuitry, or software associated with the kit to determine whether to incorporate such items in a finished product and software developers to write software applications for use with the end product. This kit is not a finished product and when assembled may not be resold or otherwise marketed unless all required FCC equipment authorizations are first obtained. Operation is subject to the condition that this product not cause harmful interference to licensed radio stations and that this product accept harmful interference. Unless the assembled kit is designed to operate under part 15, part 18 or part 95 of this chapter, the operator of the kit must operate under the authority of an FCC license holder or must secure an experimental authorization under part 5 of this chapter.

3.1.2 *For EVMs annotated as FCC – FEDERAL COMMUNICATIONS COMMISSION Part 15 Compliant:*

CAUTION

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Interference Statement for Class A EVM devices

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

FCC Interference Statement for Class B EVM devices

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- *Reorient or relocate the receiving antenna.*
- *Increase the separation between the equipment and receiver.*
- *Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.*
- *Consult the dealer or an experienced radio/TV technician for help.*

3.2 Canada

3.2.1 For EVMs issued with an Industry Canada Certificate of Conformance to RSS-210

Concerning EVMs Including Radio Transmitters:

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Concernant les EVMs avec appareils radio:

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Concerning EVMs Including Detachable Antennas:

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication. This radio transmitter has been approved by Industry Canada to operate with the antenna types listed in the user guide with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

Concernant les EVMs avec antennes détachables

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante. Le présent émetteur radio a été approuvé par Industrie Canada pour fonctionner avec les types d'antenne énumérés dans le manuel d'usage et ayant un gain admissible maximal et l'impédance requise pour chaque type d'antenne. Les types d'antenne non inclus dans cette liste, ou dont le gain est supérieur au gain maximal indiqué, sont strictement interdits pour l'exploitation de l'émetteur.

3.3 Japan

3.3.1 *Notice for EVMs delivered in Japan:* Please see http://www.tij.co.jp/llds/ti_ja/general/eStore/notice_01.page 日本国内に輸入される評価用キット、ボードについては、次のところをご覧ください。
http://www.tij.co.jp/llds/ti_ja/general/eStore/notice_01.page

3.3.2 *Notice for Users of EVMs Considered "Radio Frequency Products" in Japan:* EVMs entering Japan may not be certified by TI as conforming to Technical Regulations of Radio Law of Japan.

If User uses EVMs in Japan, not certified to Technical Regulations of Radio Law of Japan, User is required by Radio Law of Japan to follow the instructions below with respect to EVMs:

1. Use EVMs in a shielded room or any other test facility as defined in the notification #173 issued by Ministry of Internal Affairs and Communications on March 28, 2006, based on Sub-section 1.1 of Article 6 of the Ministry's Rule for Enforcement of Radio Law of Japan,
2. Use EVMs only after User obtains the license of Test Radio Station as provided in Radio Law of Japan with respect to EVMs, or
3. Use of EVMs only after User obtains the Technical Regulations Conformity Certification as provided in Radio Law of Japan with respect to EVMs. Also, do not transfer EVMs, unless User gives the same notice above to the transferee. Please note that if User does not follow the instructions above, User will be subject to penalties of Radio Law of Japan.

【無線電波を送信する製品の開発キットをお使いになる際の注意事項】 開発キットの中には技術基準適合証明を受けていないものがあります。技術適合証明を受けていないもののご使用に際しては、電波法遵守のため、以下のいずれかの措置を取っていただく必要がありますのでご注意ください。

1. 電波法施行規則第6条第1項第1号に基づく平成18年3月28日総務省告示第173号で定められた電波暗室等の試験設備でご使用いただく。
2. 実験局の免許を取得後ご使用いただく。
3. 技術基準適合証明を取得後ご使用いただく。

なお、本製品は、上記の「ご使用にあたっての注意」を譲渡先、移転先に通知しない限り、譲渡、移転できないものとします。

上記を遵守頂けない場合は、電波法の罰則が適用される可能性があることをご留意ください。日本テキサス・インスツルメンツ株式会社
東京都新宿区西新宿 6 丁目 2 4 番 1 号
西新宿三井ビル

3.3.3 *Notice for EVMs for Power Line Communication:* Please see http://www.tij.co.jp/lstds/ti_ja/general/eStore/notice_02.page
電力線搬送波通信についての開発キットをお使いになる際の注意事項については、次のところをご覧ください。http://www.tij.co.jp/lstds/ti_ja/general/eStore/notice_02.page

4 *EVM Use Restrictions and Warnings:*

4.1 EVMS ARE NOT FOR USE IN FUNCTIONAL SAFETY AND/OR SAFETY CRITICAL EVALUATIONS, INCLUDING BUT NOT LIMITED TO EVALUATIONS OF LIFE SUPPORT APPLICATIONS.

4.2 User must read and apply the user guide and other available documentation provided by TI regarding the EVM prior to handling or using the EVM, including without limitation any warning or restriction notices. The notices contain important safety information related to, for example, temperatures and voltages.

4.3 *Safety-Related Warnings and Restrictions:*

4.3.1 User shall operate the EVM within TI's recommended specifications and environmental considerations stated in the user guide, other available documentation provided by TI, and any other applicable requirements and employ reasonable and customary safeguards. Exceeding the specified performance ratings and specifications (including but not limited to input and output voltage, current, power, and environmental ranges) for the EVM may cause personal injury or death, or property damage. If there are questions concerning performance ratings and specifications, User should contact a TI field representative prior to connecting interface electronics including input power and intended loads. Any loads applied outside of the specified output range may also result in unintended and/or inaccurate operation and/or possible permanent damage to the EVM and/or interface electronics. Please consult the EVM user guide prior to connecting any load to the EVM output. If there is uncertainty as to the load specification, please contact a TI field representative. During normal operation, even with the inputs and outputs kept within the specified allowable ranges, some circuit components may have elevated case temperatures. These components include but are not limited to linear regulators, switching transistors, pass transistors, current sense resistors, and heat sinks, which can be identified using the information in the associated documentation. When working with the EVM, please be aware that the EVM may become very warm.

4.3.2 EVMS are intended solely for use by technically qualified, professional electronics experts who are familiar with the dangers and application risks associated with handling electrical mechanical components, systems, and subsystems. User assumes all responsibility and liability for proper and safe handling and use of the EVM by User or its employees, affiliates, contractors or designees. User assumes all responsibility and liability to ensure that any interfaces (electronic and/or mechanical) between the EVM and any human body are designed with suitable isolation and means to safely limit accessible leakage currents to minimize the risk of electrical shock hazard. User assumes all responsibility and liability for any improper or unsafe handling or use of the EVM by User or its employees, affiliates, contractors or designees.

4.4 User assumes all responsibility and liability to determine whether the EVM is subject to any applicable international, federal, state, or local laws and regulations related to User's handling and use of the EVM and, if applicable, User assumes all responsibility and liability for compliance in all respects with such laws and regulations. User assumes all responsibility and liability for proper disposal and recycling of the EVM consistent with all applicable international, federal, state, and local requirements.

5. *Accuracy of Information:* To the extent TI provides information on the availability and function of EVMS, TI attempts to be as accurate as possible. However, TI does not warrant the accuracy of EVM descriptions, EVM availability or other information on its websites as accurate, complete, reliable, current, or error-free.

6. *Disclaimers:*

6.1 EXCEPT AS SET FORTH ABOVE, EVMS AND ANY WRITTEN DESIGN MATERIALS PROVIDED WITH THE EVM (AND THE DESIGN OF THE EVM ITSELF) ARE PROVIDED "AS IS" AND "WITH ALL FAULTS." TI DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, REGARDING SUCH ITEMS, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF ANY THIRD PARTY PATENTS, COPYRIGHTS, TRADE SECRETS OR OTHER INTELLECTUAL PROPERTY RIGHTS.

6.2 EXCEPT FOR THE LIMITED RIGHT TO USE THE EVM SET FORTH HEREIN, NOTHING IN THESE TERMS AND CONDITIONS SHALL BE CONSTRUED AS GRANTING OR CONFERRING ANY RIGHTS BY LICENSE, PATENT, OR ANY OTHER INDUSTRIAL OR INTELLECTUAL PROPERTY RIGHT OF TI, ITS SUPPLIERS/LICENSORS OR ANY OTHER THIRD PARTY, TO USE THE EVM IN ANY FINISHED END-USER OR READY-TO-USE FINAL PRODUCT, OR FOR ANY INVENTION, DISCOVERY OR IMPROVEMENT MADE, CONCEIVED OR ACQUIRED PRIOR TO OR AFTER DELIVERY OF THE EVM.

7. *USER'S INDEMNITY OBLIGATIONS AND REPRESENTATIONS.* USER WILL DEFEND, INDEMNIFY AND HOLD TI, ITS LICENSORS AND THEIR REPRESENTATIVES HARMLESS FROM AND AGAINST ANY AND ALL CLAIMS, DAMAGES, LOSSES, EXPENSES, COSTS AND LIABILITIES (COLLECTIVELY, "CLAIMS") ARISING OUT OF OR IN CONNECTION WITH ANY HANDLING OR USE OF THE EVM THAT IS NOT IN ACCORDANCE WITH THESE TERMS AND CONDITIONS. THIS OBLIGATION SHALL APPLY WHETHER CLAIMS ARISE UNDER STATUTE, REGULATION, OR THE LAW OF TORT, CONTRACT OR ANY OTHER LEGAL THEORY, AND EVEN IF THE EVM FAILS TO PERFORM AS DESCRIBED OR EXPECTED.

8. *Limitations on Damages and Liability:*

8.1 *General Limitations.* IN NO EVENT SHALL TI BE LIABLE FOR ANY SPECIAL, COLLATERAL, INDIRECT, PUNITIVE, INCIDENTAL, CONSEQUENTIAL, OR EXEMPLARY DAMAGES IN CONNECTION WITH OR ARISING OUT OF THESE TERMS AND CONDITIONS OR THE USE OF THE EVMS PROVIDED HEREUNDER, REGARDLESS OF WHETHER TI HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. EXCLUDED DAMAGES INCLUDE, BUT ARE NOT LIMITED TO, COST OF REMOVAL OR REINSTALLATION, ANCILLARY COSTS TO THE PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES, RETESTING, OUTSIDE COMPUTER TIME, LABOR COSTS, LOSS OF GOODWILL, LOSS OF PROFITS, LOSS OF SAVINGS, LOSS OF USE, LOSS OF DATA, OR BUSINESS INTERRUPTION. NO CLAIM, SUIT OR ACTION SHALL BE BROUGHT AGAINST TI MORE THAN ONE YEAR AFTER THE RELATED CAUSE OF ACTION HAS OCCURRED.

8.2 *Specific Limitations.* IN NO EVENT SHALL TI'S AGGREGATE LIABILITY FROM ANY WARRANTY OR OTHER OBLIGATION ARISING OUT OF OR IN CONNECTION WITH THESE TERMS AND CONDITIONS, OR ANY USE OF ANY TI EVM PROVIDED HEREUNDER, EXCEED THE TOTAL AMOUNT PAID TO TI FOR THE PARTICULAR UNITS SOLD UNDER THESE TERMS AND CONDITIONS WITH RESPECT TO WHICH LOSSES OR DAMAGES ARE CLAIMED. THE EXISTENCE OF MORE THAN ONE CLAIM AGAINST THE PARTICULAR UNITS SOLD TO USER UNDER THESE TERMS AND CONDITIONS SHALL NOT ENLARGE OR EXTEND THIS LIMIT.

9. *Return Policy.* Except as otherwise provided, TI does not offer any refunds, returns, or exchanges. Furthermore, no return of EVM(s) will be accepted if the package has been opened and no return of the EVM(s) will be accepted if they are damaged or otherwise not in a resalable condition. If User feels it has been incorrectly charged for the EVM(s) it ordered or that delivery violates the applicable order, User should contact TI. All refunds will be made in full within thirty (30) working days from the return of the components(s), excluding any postage or packaging costs.

10. *Governing Law:* These terms and conditions shall be governed by and interpreted in accordance with the laws of the State of Texas, without reference to conflict-of-laws principles. User agrees that non-exclusive jurisdiction for any dispute arising out of or relating to these terms and conditions lies within courts located in the State of Texas and consents to venue in Dallas County, Texas. Notwithstanding the foregoing, any judgment may be enforced in any United States or foreign court, and TI may seek injunctive relief in any United States or foreign court.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265
Copyright © 2015, Texas Instruments Incorporated

IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, enhancements, improvements and other changes to its semiconductor products and services per JESD46, latest issue, and to discontinue any product or service per JESD48, latest issue. Buyers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All semiconductor products (also referred to herein as "components") are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its components to the specifications applicable at the time of sale, in accordance with the warranty in TI's terms and conditions of sale of semiconductor products. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by applicable law, testing of all parameters of each component is not necessarily performed.

TI assumes no liability for applications assistance or the design of Buyers' products. Buyers are responsible for their products and applications using TI components. To minimize the risks associated with Buyers' products and applications, Buyers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any patent right, copyright, mask work right, or other intellectual property right relating to any combination, machine, or process in which TI components or services are used. Information published by TI regarding third-party products or services does not constitute a license to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of significant portions of TI information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. TI is not responsible or liable for such altered documentation. Information of third parties may be subject to additional restrictions.

Resale of TI components or services with statements different from or beyond the parameters stated by TI for that component or service voids all express and any implied warranties for the associated TI component or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

Buyer acknowledges and agrees that it is solely responsible for compliance with all legal, regulatory and safety-related requirements concerning its products, and any use of TI components in its applications, notwithstanding any applications-related information or support that may be provided by TI. Buyer represents and agrees that it has all the necessary expertise to create and implement safeguards which anticipate dangerous consequences of failures, monitor failures and their consequences, lessen the likelihood of failures that might cause harm and take appropriate remedial actions. Buyer will fully indemnify TI and its representatives against any damages arising out of the use of any TI components in safety-critical applications.

In some cases, TI components may be promoted specifically to facilitate safety-related applications. With such components, TI's goal is to help enable customers to design and create their own end-product solutions that meet applicable functional safety standards and requirements. Nonetheless, such components are subject to these terms.

No TI components are authorized for use in FDA Class III (or similar life-critical medical equipment) unless authorized officers of the parties have executed a special agreement specifically governing such use.

Only those TI components which TI has specifically designated as military grade or "enhanced plastic" are designed and intended for use in military/aerospace applications or environments. Buyer acknowledges and agrees that any military or aerospace use of TI components which have **not** been so designated is solely at the Buyer's risk, and that Buyer is solely responsible for compliance with all legal and regulatory requirements in connection with such use.

TI has specifically designated certain components as meeting ISO/TS16949 requirements, mainly for automotive use. In any case of use of non-designated products, TI will not be responsible for any failure to meet ISO/TS16949.

Products

Audio	www.ti.com/audio
Amplifiers	amplifier.ti.com
Data Converters	dataconverter.ti.com
DLP® Products	www.dlp.com
DSP	dsp.ti.com
Clocks and Timers	www.ti.com/clocks
Interface	interface.ti.com
Logic	logic.ti.com
Power Mgmt	power.ti.com
Microcontrollers	microcontroller.ti.com
RFID	www.ti-rfid.com
OMAP Applications Processors	www.ti.com/omap
Wireless Connectivity	www.ti.com/wirelessconnectivity

Applications

Automotive and Transportation	www.ti.com/automotive
Communications and Telecom	www.ti.com/communications
Computers and Peripherals	www.ti.com/computers
Consumer Electronics	www.ti.com/consumer-apps
Energy and Lighting	www.ti.com/energy
Industrial	www.ti.com/industrial
Medical	www.ti.com/medical
Security	www.ti.com/security
Space, Avionics and Defense	www.ti.com/space-avionics-defense
Video and Imaging	www.ti.com/video

TI E2E Community

e2e.ti.com