







F

E

D

C

B

A

F

E

D



C

B



A

SLA3_BUSS_JANE_GERBL_REV_A

8		7		6		5		4		3		2		1	
CATALOG NO.	TERMINAL TYPE	IP20 FINGER SAFE C		NO. OF POLES											
		W/O INDICATION	INDICATION												
HM60030-1SR	SCREW	CVR-RH-60030	CVRI-RH-60030	1											
HM60030-2SR	SCREW			2											
HM60030-3SR	SCREW			3											
HM60030-1PR	PRESSURE PLATE			1											
HM60030-2PR	PRESSURE PLATE			2											
HM60030-3PR	PRESSURE PLATE			3											
HM60030-1CR	BOX LUG			1											
HM60030-2CR	BOX LUG			2											
HM60030-3CR	BOX LUG			3											
HM60030-1MW14	BOX LUG - 4 PORT MULTIWI	NA	NA	1											
HM60030-2MW14	BOX LUG - 4 PORT MULTIWI			2											
HM60030-3MW14	BOX LUG - 4 PORT MULTIWI			3											
* -CHR ALSO AVAILABLE; SEE NOTE 11															




CLOSING
PUSH STRAIGHT DOWN UNTIL SNAPS CLICK INTO PLACE




OPENING
PULL STRAIGHT UP AT BOTH OUTSIDE HANDLES


CUT COVER TAB AT NOTCH FOR WIRES LARGER THAN 8 AWG



DETAIL A
SCALE 1.5 : 1




A



1. HOOK DIN RAIL SNAPS ON ONE SIDE OF THE DIN RAIL

2. PUSH DOWN TO DEFLECT THE SNAPS



3. ROTATE UNTIL THE OPPOSITE SIDE SNAPS ONTO DIN RAIL

INSTALLATION ON DIN RAIL
END STOPS MAY BE NECESSARY FOR SOME ASSEMBLY CONDITIONS - SEE NOTE 7

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Eaton:

[HM60030-2PR](#) [HM60030-1CR](#) [HM60030-3SR](#) [HM60030-2CR](#) [HM60030-2SR](#) [HM60030-1SR](#) [HM60030-3PR](#)
[HM60030-1PR](#) [HM60030-3CR](#) [RM60030-2SR](#) [RM60030-2PR](#) [RM60030-3SR](#) [RM60030-3CR](#) [RM60030-3PR](#)
[RM60030-1CHR](#) [RM60030-1SR](#) [RM60030-1CR](#) [RM60030-1PR](#) [RM60030-1MW14](#) [RM60030-2CHR](#) [RM60030-2MW14](#) [RM60030-3CHR](#) [RM60030-3MW14](#) [RM60030-2CR](#)