

MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918

Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com

eFuse 7 Click





PID: MIKROE-5738

eFuse 7 Click is a compact add-on board with a power path protection solution that limits circuit currents and voltages to safe levels during fault conditions. This board features the <u>LS12052BD33</u>, an eFuse with over-voltage protection and blocking FET control from <u>Littelfuse</u>. This industrial eFuse has a wide input voltage from 2.7V up to 18V, external programmable soft-start time, and current limit, and supports reverse current blocking. Besides, it features short-circuit protection, thermal shutdown protection, and auto recovery. This Click board ™ makes the perfect solution for the development of robust protection for multiple faults on the system rail and current limiting for systems such as telecom radios and industrial printers.

How does it work?

eFuse 7 Click is based on the LS12052BD33, an eFuse with over-voltage protection and blocking FET control from Littelfuse. It is a current limit load switch with an integrated power load switch designed to manage current/voltage/start-up voltage ramp to the connected load. The internal MOSFET of the device will start conducting and allowing current to flow from IN to OUT as VIN rises by enabling the eFuse with an accurate ON/OFF threshold of 1.29V and 1.19V, respectively. After a Start-Up sequence, the eFuse will actively monitor its load current and input voltage. The eFuse will ensure that any harmful spikes are safely clamped to a predetermined level at the output. The eFuse will shut down its internal MOSFET if the overload of the current limit is exceeded or the device's temperature exceeds its threshold.

Mikroe produces entire development toolchains for all major microcontroller architectures.

Committed to excellency, we are dedicated to helping engineers bring the project development up to speed and achieve outstanding results.








MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918

Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com



The eFuse uses the <u>TP86R203N</u>L, an N-channel MOS from Toshiba, as a gate to the output screw terminal. The current limit on this eFuse 7 Click can be programmed. For this purpose, there is the AD5227, a 64-position up/down control digital potentiometer from Analog Devices. This 10K end-to-end potentiometer, in variable resistor configuration, is used to feed the current limit program pin of the eFuse.

eFuse 7 Click uses a simple 3-Wire serial interface of the digital potentiometer to allow the host MCU to set the current limit to this Click board $^{\text{TM}}$. Over the RST pin, you can enable the eFuse with the logic HIGH.

This Click board[™] can operate with either 3.3V or 5V logic voltage levels selected via the VIO SEL jumper. This way, both 3.3V and 5V capable MCUs can use the communication lines properly. However, the Click board[™] comes equipped with a library containing easy-to-use functions and an example code that can be used, as a reference, for further development.

Specifications

Туре	Power Switch
Applications	Can be used for the development of robust protection for multiple faults on the system rail and current limiting for systems such as telecom radios and industrial printers
On-board modules	LS12052BD33 - eFuse with over-voltage protection and blocking FET control from Littelfuse
Key Features	Wide operating voltage, adjusting current limit, short-circuit protection features, thermal shutdown protection, and auto recovery, reverse current blocking and more
Interface	GPIO
Feature	ClickID
Compatibility	mikroBUS™
Click board size	M (42.9 x 25.4 mm)
Input Voltage	3.3V or 5V

Mikroe produces entire development toolchains for all major microcontroller architectures.

Committed to excellency, we are dedicated to helping engineers bring the project development up to speed and achieve outstanding results.







MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918

Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com

www.mikroe.com

Pinout diagram

This table shows how the pinout on eFuse 7 Click corresponds to the pinout on the mikroBUS™ socket (the latter shown in the two middle columns).

Notes	Pin	nikro™ BUS				Pin	Notes
	NC	1	AN	PWM	16	NC	
Reset / ID SEL	RST	2	RST	INT	15	NC	
SPI Select / ID COMM	CS	3	CS	RX	14	NC	
SPI Clock	SCK	4	SCK	TX	13	NC	
	NC	5	MISO	SCL	12	NC	
SPI Data IN	SDI	6	MOSI	SDA	11	NC	
Power Supply	3.3V	7	3.3V	5V	10	5V	Power Supply
Ground	GND	8	GND	GND	9	GND	Ground

Onboard settings and indicators

Label	Name	Default	Description
LD1	PWR	-	Power LED Indicator
JP1	VIO SEL		Logic Level Voltage Selection 3V3/5V: Left position 3V3, Right position 5V

eFuse 7 Click electrical specifications

Description	Min	Тур	Max	Unit
Supply Voltage	3.3	-	5	V
External Power Supply	2.7	-	18	V
Current-Limit Program Range	1	-	5	A

Software Support

We provide a library for the eFuse 7 Click as well as a demo application (example), developed using MIKROE compilers. The demo can run on all the main MIKROE development boards.

Package can be downloaded/installed directly from NECTO Studio Package Manager (recommended), downloaded from our <u>LibStock™</u> or found on <u>Mikroe github account</u>.

Library Description

This library contains API for eFuse 7 Click driver.

Key functions

- efuse7 enable output eFuse 7 output enable function.
- efuse7_wiper_inc eFuse 7 wiper position increase function.
- efuse7_set_limit eFuse 7 set current limit function.

Mikroe produces entire development toolchains for all major microcontroller architectures. Committed to excellency, we are dedicated to helping engineers bring the project development up to speed and achieve outstanding results.









MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918

Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com

Example Description

This library contains API for the eFuse 7 Click driver. This driver provides the functions to set the current limiting conditions in order to provide the threshold of the fault conditions.

The full application code, and ready to use projects can be installed directly from NECTO Studio Package Manager (recommended), downloaded from our <u>LibStock™</u> or found on <u>Mikroe github</u> account.

Other Mikroe Libraries used in the example:

- MikroSDK.Board
- MikroSDK.Log
- Click.eFuse7

Additional notes and informations

Depending on the development board you are using, you may need <u>USB UART click</u>, <u>USB UART 2 Click</u> or <u>RS232 Click</u> to connect to your PC, for development systems with no UART to USB interface available on the board. UART terminal is available in all MIKROE <u>compilers</u>.

mikroSDK

This Click board[™] is supported with $\underline{\mathsf{mikroSDK}}$ - MIKROE Software Development Kit. To ensure proper operation of mikroSDK compliant Click board[™] demo applications, mikroSDK should be downloaded from the $\underline{\mathsf{LibStock}}$ and installed for the compiler you are using.

For more information about mikroSDK, visit the official page.

Resources

mikroBUS™

mikroSDK

Click board™ Catalog

Click boards™

ClickID

Downloads

eFuse 7 click example on Libstock

TP86R203NL datasheet

LS12052BD33 datasheet

eFuse 7 click 2D and 3D files

eFuse 7 click schematic

Mikroe produces entire development toolchains for all major microcontroller architectures.

Committed to excellency, we are dedicated to helping engineers bring the project development up to speed and achieve outstanding results.



