



Faster, Simpler, Convenient testing of ASD systems

Using Solo 365 to test aspirating detector test points is easy:

Simply replace the clear test cup with the new exclusive ASD Adaptor and use the 'Delayed Start Mode' to allow smoke to be directed into an accessible sampling hole along the pipe run.

Testing an ASD System

The ASD Adaptor is an optional extra available from your usual distributor; it is easily fitted to Solo 365 following the instructions below:

- With the Solo 365 facing you, remove the cup by aligning the notch on the left hand side arm and disengage by squeezing the cup and gently pulling the arm outwards
- Rotate the cup to free it from the other arm
- Fit the ASD adaptor by locating into both arms
- Power Solo 365 on
- Select the 'Delayed Start Mode' by pressing the 'function button' – the status LEDs will flash orange
- Raise Solo 365 over the sampling hole on the aspirating pipe to carry out the test
- Smoke will automatically be generated indicated by the status LEDs flashing blue

Product Code: Solo 372-001

