SIEMENS

Data sheet 3RV2421-4DA20



Circuit breaker size S0 for transformer protection A-release 18...25 A N-release 400 A Spring-type terminal Standard switching capacity



product brand name	SIRIUS	
product designation	Circuit breaker	
design of the product	For transformer protection	
product type designation	3RV2	
General technical data		
size of the circuit-breaker	S0	
size of contactor can be combined company-specific	S00, S0	
product extension auxiliary switch	Yes	
power loss [W] for rated value of the current		
 at AC in hot operating state 	10.5 W	
 at AC in hot operating state per pole 	3.5 W	
insulation voltage with degree of pollution 3 at AC rated value	690 V	
surge voltage resistance rated value	6 kV	
shock resistance according to IEC 60068-2-27	25g / 11 ms	
mechanical service life (operating cycles)		
 of the main contacts typical 	100 000	
 of auxiliary contacts typical 	100 000	
electrical endurance (operating cycles) typical	100 000	
reference code according to IEC 81346-2	Q	
Substance Prohibitance (Date)	10/01/2009	
SVHC substance name	Lead - 7439-92-1	
Ambient conditions		
installation altitude at height above sea level maximum	2 000 m	
ambient temperature		
 during operation 	-20 +60 °C	
during storage	-50 +80 °C	
during transport	-50 +80 °C	
relative humidity during operation	10 95 %	
Main circuit		
number of poles for main current circuit	3	
adjustable current response value current of the current- dependent overload release	18 25 A	
operating voltage		
rated value	20 690 V	
 at AC-3 rated value maximum 	690 V	
at AC-3e rated value maximum	690 V	
operating frequency rated value	50 60 Hz	

on overtional coverage water described	2F A
operational current rated value	25 A
operational current	05.4
at AC-3 at 400 V rated value	25 A
at AC-3e at 400 V rated value	25 A
operating power	
• at AC-3	
— at 230 V rated value	5.5 kW
— at 400 V rated value	11 kW
— at 500 V rated value	15 kW
— at 690 V rated value	22 kW
• at AC-3e	
— at 230 V rated value	5.5 kW
— at 400 V rated value	11 kW
— at 500 V rated value	15 kW
— at 690 V rated value	22 kW
operating frequency	
• at AC-3 maximum	15 1/h
at AC-3e maximum	15 1/h
Auxiliary circuit	
number of NC contacts for auxiliary contacts	0
number of NO contacts for auxiliary contacts	0
number of CO contacts for auxiliary contacts	0
Protective and monitoring functions	
product function	
ground fault detection	No
 phase failure detection 	Yes
trip class	CLASS 10
design of the overload release	thermal
maximum short-circuit current breaking capacity (Icu)	
• at AC at 240 V rated value	100 kA
• at AC at 400 V rated value	55 kA
• at AC at 500 V rated value	10 kA
• at AC at 690 V rated value	4 kA
operating short-circuit current breaking capacity (Ics) at AC	
• at 240 V rated value	100 kA
• at 400 V rated value	25 kA
• at 500 V rated value	5 kA
• at 690 V rated value	2 kA
response value current of instantaneous short-circuit trip unit	400 A
UL/CSA ratings	
full-load current (FLA) for 3-phase AC motor	
at 480 V rated value	25 A
at 600 V rated value	25 A
yielded mechanical performance [hp]	
• for single-phase AC motor	
— at 110/120 V rated value	2 hp
— at 230 V rated value	3 hp
• for 3-phase AC motor	
— at 200/208 V rated value	5 hp
— at 220/230 V rated value	7.5 hp
— at 460/480 V rated value	15 hp
Short-circuit protection	, o p
product function short circuit protection	Yes
design of the short-circuit trip	
	magnetic
design of the fuse link for IT network for short-circuit protection of the main circuit	
• at 400 V	gL/gG 63 A
• at 500 V	gL/gG 50 A
• at 690 V	gL/gG 50 A
Installation/ mounting/ dimensions	
mounting position	any
meaning position	uny

eight ridth epth equired spacing • with side-by-side mounting at the side • for grounded parts at 400 V — downwards — upwards — at the side • for live parts at 400 V — downwards — at the side • for grounded parts at 500 V — downwards — upwards — at the side • for live parts at 500 V — downwards — upwards — at the side • for live parts at 500 V — downwards — at the side • for live parts at 500 V — downwards — at the side • for live parts at 690 V — downwards — upwards — at the side • for grounded parts at 690 V — downwards — backwards — at the side — forwards • for live parts at 690 V — downwards — backwards — at the side — forwards — backwards • for live parts at 690 V — downwards — backwards • for live parts at 690 V — downwards — backwards — backwards — backwards	screw and snap-on mounting onto 35 mm DIN rail according to DIN EN 60715 119 mm 45 mm 97 mm 0 mm 30 mm
epth equired spacing • with side-by-side mounting at the side • for grounded parts at 400 V — downwards — upwards — at the side • for live parts at 400 V — downwards — upwards — at the side • for grounded parts at 500 V — downwards — upwards — at the side • for live parts at 500 V — downwards — upwards — at the side • for live parts at 500 V — downwards — upwards — at the side • for grounded parts at 690 V — downwards — upwards — at the side • for grounded parts at 690 V — downwards — backwards — at the side — forwards • for live parts at 690 V — downwards — backwards — at the side — forwards • for live parts at 690 V — downwards — backwards — backwards • for live parts at 690 V — downwards — backwards • for live parts at 690 V — downwards — backwards — backwards	97 mm 0 mm 30 mm 30 mm 9 mm 30 mm 9 mm 30 mm 30 mm 30 mm
equired spacing with side-by-side mounting at the side for grounded parts at 400 V — downwards — upwards — at the side for live parts at 400 V — downwards — upwards — at the side for grounded parts at 500 V — downwards — upwards — at the side for live parts at 500 V — downwards — upwards — at the side for grounded parts at 500 V — downwards — upwards — at the side for live parts at 690 V — downwards — upwards — at the side for grounded parts at 690 V — downwards — backwards — at the side — forwards — at the side — forwards — at the side — forwards — at the side — forwards — backwards — at the side — forwards • for live parts at 690 V — downwards — backwards — at the side — forwards • for live parts at 690 V — downwards — backwards	0 mm 30 mm 30 mm 9 mm 30 mm 30 mm 30 mm 30 mm
• with side-by-side mounting at the side • for grounded parts at 400 V — downwards — upwards — at the side • for live parts at 400 V — downwards — upwards — at the side • for grounded parts at 500 V — downwards — upwards — at the side • for live parts at 500 V — downwards — upwards — at the side • for live parts at 500 V — downwards — upwards — at the side • for grounded parts at 690 V — downwards — upwards — at the side • for grounded parts at 690 V — downwards — upwards — backwards — at the side — forwards • for live parts at 690 V — downwards — upwards — backwards • for live parts at 690 V — downwards — backwards — at the side — forwards • for live parts at 690 V — downwards — backwards • for live parts at 690 V — downwards — backwards	30 mm 30 mm 9 mm 30 mm 30 mm 30 mm 30 mm
for grounded parts at 400 V — downwards — upwards — at the side for live parts at 400 V — downwards — upwards — at the side for grounded parts at 500 V — downwards — upwards — upwards — at the side for live parts at 500 V — downwards — upwards — at the side for live parts at 500 V — downwards — upwards — at the side for grounded parts at 690 V — downwards — upwards — at the side for grounded parts at 690 V — downwards — at the side — forwards — at the side — forwards for live parts at 690 V — downwards — at the side — forwards for live parts at 690 V — downwards — at the side — forwards for live parts at 690 V — downwards — at the side — forwards for live parts at 690 V — downwards — backwards for live parts at 690 V — downwards — backwards	30 mm 30 mm 9 mm 30 mm 30 mm 30 mm 30 mm
for grounded parts at 400 V — downwards — upwards — at the side for live parts at 400 V — downwards — upwards — at the side for grounded parts at 500 V — downwards — upwards — upwards — at the side for live parts at 500 V — downwards — upwards — at the side for live parts at 500 V — downwards — upwards — at the side for grounded parts at 690 V — downwards — upwards — at the side for grounded parts at 690 V — downwards — at the side — forwards — at the side — forwards for live parts at 690 V — downwards — at the side — forwards for live parts at 690 V — downwards — at the side — forwards for live parts at 690 V — downwards — at the side — forwards for live parts at 690 V — downwards — backwards for live parts at 690 V — downwards — backwards	30 mm 9 mm 30 mm 30 mm 9 mm
— downwards — upwards — at the side • for live parts at 400 V — downwards — upwards — at the side • for grounded parts at 500 V — downwards — upwards — at the side • for live parts at 500 V — downwards — upwards — at the side • for grounded parts at 690 V — downwards — upwards — at the side • for grounded parts at 690 V — downwards — upwards — backwards — at the side • for live parts at 690 V — downwards — upwards — backwards • for live parts at 690 V — downwards — at the side — forwards • for live parts at 690 V — downwards — at the side — forwards • for live parts at 690 V — downwards — backwards	30 mm 9 mm 30 mm 30 mm 9 mm
 upwards at the side for live parts at 400 V downwards upwards at the side for grounded parts at 500 V downwards upwards at the side for live parts at 500 V downwards upwards at the side for live parts at 500 V downwards upwards at the side for grounded parts at 690 V downwards upwards upwards at the side for grounded parts at 690 V downwards at the side for live parts at 690 V downwards at the side for live parts at 690 V downwards for live parts at 690 V downwards backwards backwards 	9 mm 30 mm 30 mm 9 mm
- at the side • for live parts at 400 V - downwards - upwards - at the side • for grounded parts at 500 V - downwards - upwards - at the side • for live parts at 500 V - downwards - upwards - at the side • for grounded parts at 690 V - downwards - upwards - at the side • for grounded parts at 690 V - downwards - upwards - backwards - at the side - forwards • for live parts at 690 V - downwards - at the side - forwards • for live parts at 690 V - downwards - upwards - backwards	9 mm 30 mm 30 mm 9 mm
for live parts at 400 V — downwards — upwards — at the side for grounded parts at 500 V — downwards — upwards — at the side for live parts at 500 V — downwards — at the side for live parts at 500 V — downwards — upwards — at the side for grounded parts at 690 V — downwards — upwards — upwards — backwards — at the side — forwards • for live parts at 690 V — downwards — at the side — forwards • for live parts at 690 V — downwards — at the side — forwards • for live parts at 690 V — downwards — upwards — upwards — backwards	30 mm 30 mm 9 mm
- downwards - upwards - at the side • for grounded parts at 500 V - downwards - upwards - at the side • for live parts at 500 V - downwards - upwards - at the side • for grounded parts at 690 V - downwards - upwards - upwards - backwards - at the side - forwards - upwards - backwards - at the side - forwards - upwards - backwards - at the side - forwards - upwards - backwards - upwards - backwards - upwards - backwards	30 mm 9 mm 30 mm
- upwards - at the side • for grounded parts at 500 V - downwards - upwards - at the side • for live parts at 500 V - downwards - upwards - at the side • for grounded parts at 690 V - downwards - upwards - upwards - upwards - backwards - at the side - forwards - at the side - forwards - at the side - forwards - upwards - at the side - forwards - upwards - backwards - upwards - upwards - backwards - upwards - backwards	30 mm 9 mm 30 mm
— at the side • for grounded parts at 500 V — downwards — upwards — at the side • for live parts at 500 V — downwards — upwards — at the side • for grounded parts at 690 V — downwards — upwards — upwards — backwards — at the side • for live parts at 690 V — downwards — upwards — backwards — at the side — forwards • for live parts at 690 V — downwards — upwards — backwards	9 mm 30 mm
for grounded parts at 500 V — downwards — upwards — at the side for live parts at 500 V — downwards — upwards — upwards — at the side for grounded parts at 690 V — downwards — upwards — upwards — backwards — at the side — forwards — forwards — for live parts at 690 V — downwards — upwards — upwards — for live parts at 690 V — downwards — upwards — upwards — upwards — backwards	30 mm
 downwards upwards at the side for live parts at 500 V downwards upwards at the side for grounded parts at 690 V downwards upwards upwards at the side for grounded parts at 690 V downwards upwards packwards at the side forwards for live parts at 690 V downwards powards upwards upwards upwards backwards 	
 upwards at the side for live parts at 500 V downwards upwards at the side for grounded parts at 690 V downwards upwards upwards backwards at the side for wards for live parts at 690 V downwards at the side for live parts at 690 V downwards packwards for live parts at 690 V downwards upwards upwards backwards 	
— at the side • for live parts at 500 V — downwards — upwards — at the side • for grounded parts at 690 V — downwards — upwards — backwards — at the side — forwards • for live parts at 690 V — downwards — upwards — at the side — forwards • for live parts at 690 V — downwards — upwards — upwards — upwards — upwards — backwards	30 111111
for live parts at 500 V — downwards — upwards — at the side • for grounded parts at 690 V — downwards — upwards — upwards — backwards — at the side — forwards • for live parts at 690 V — downwards • parts at 690 V — downwards — upwards — upwards — upwards — upwards — backwards	9 mm
 downwards upwards at the side for grounded parts at 690 V downwards upwards backwards at the side for wards for live parts at 690 V downwards power of the side upwards for live parts at 690 V downwards upwards backwards 	V IIIII
 upwards at the side for grounded parts at 690 V downwards upwards backwards at the side forwards for live parts at 690 V downwards upwards backwards downwards upwards backwards 	30 mm
- at the side • for grounded parts at 690 V - downwards - upwards - backwards - at the side - forwards • for live parts at 690 V - downwards - upwards - upwards - backwards	30 mm
for grounded parts at 690 V — downwards — upwards — backwards — at the side — forwards • for live parts at 690 V — downwards — upwards — upwards — backwards	
 — downwards — upwards — backwards — at the side — forwards ● for live parts at 690 V — downwards — upwards — backwards 	9 mm
 — upwards — backwards — at the side — forwards • for live parts at 690 V — downwards — upwards — backwards 	50
— backwards — at the side — forwards • for live parts at 690 V — downwards — upwards — backwards (0)	50 mm
 — at the side — forwards ● for live parts at 690 V — downwards — upwards — backwards 	50 mm
— forwards • for live parts at 690 V — downwards — upwards — backwards	0 mm
 for live parts at 690 V — downwards — upwards — backwards 	30 mm
downwardsupwardsbackwards	0 mm
upwardsbackwards	
— backwards	50 mm
	50 mm
	0 mm
— at the side	30 mm
	0 mm
nnections/ Terminals	
pe of electrical connection	
• for main current circuit	spring-loaded terminals
rrangement of electrical connectors for main current ircuit	Top and bottom
/pe of connectable conductor cross-sections	
• for main contacts	
	2x (1 10 mm²)
	2x (1 6 mm²)
	2x (1 6 mm²) 2x (18 8)
	Diameter 3 mm
	3,0 x 0,5 mm
fety related data	V
,	Yes
uitability for use	
,	No .
	Yes
	10 a
·	
roportion of dangerous failures	Yes
· ·	Yes
ē ē	Yes 40 %
10 value with high demand rate according to SN 31920	Yes 40 % 50 %
ailure rate [FIT] with low demand rate according to SN 1920 SO 13849	Yes 40 %

device type according to ISO 13849-1	3
overdimensioning according to ISO 13849-2 necessary	Yes
IEC 61508	
safety device type according to IEC 61508-2	Type A
T1 value	
 for proof test interval or service life according to IEC 61508 	10 a
Electrical Safety	
protection class IP on the front according to IEC 60529	IP20
touch protection on the front according to IEC 60529	finger-safe, for vertical contact from the front
Display	
display version for switching status	Handle
Approvals Certificates	

General Product Approval





Confirmation





KC

General Product Approval

Test Certificates

Marine / Shipping



Type Test Certificates/Test Report

Special Test Certificate







Marine / Shipping







Miscellaneous

other

Confirmation



Railway

Environment

Special Test Certific-<u>ate</u>

Confirmation



Siemens **EcoTech**



Environmental Confirmations

Information on the packaging

https://support.industry.siemens.com/cs/ww/en/view/109813875

Information- and Downloadcenter (Catalogs, Brochures,...)

Industry Mall (Online ordering system)

https://mall.industry.siemens.com/mall/en/en/Catalog/product?mlfb=3RV2421-4DA20

Cax online generator

http://support.automation.siemens.com/WW/CAXorder/default.aspx?lang=en&mlfb=3RV2421-4DA20

Service&Support (Manuals, Certificates, Characteristics, FAQs,...)

https://support.industry.siemens.com/cs/ww/en/ps/3RV2421-4DA2

Image database (product images, 2D dimension drawings, 3D models, device circuit diagrams, EPLAN macros, ...)


http://www.automation.siemens.com/bilddb/cax_de.aspx?mlfb=3RV2421-4DA20&lang=en


Characteristic: Tripping characteristics, I2t, Let-through current


https://support.industry.siemens.com/cs/ww/en/ps/3RV2421-4DA20/char

Further characteristics (e.g. electrical endurance, switching frequency)

earch&mlfb=3RV2421-4DA20&objecttype=14&gridview=view1









last modified: 4/12/2024 🖸